

## Akcesoria



Artykuł nr	Promień	Otwór	Gwint
	mm	Ø mm	
15 21 20	16,85	12,0	-
15 21 21	21,20	12,0	-
15 21 30	16,85	-	M 10
15 21 31	21,20	-	M 10



Artykuł nr	Promień	Otwór	Gwint
	mm	Ø mm	
15 21 50	16,85	8,5	-
15 21 51	21,20	8,5	-
15 21 60	16,85	-	M 8
15 21 61	21,20	-	M 8



Artykuł nr	Gwint	Długość
		mm
15 29 96	M 6	30,0
15 29 90	M 10	30,0



Artykuł nr	Gwint
90 25 10	M 10
90 25 12	M 12



Artykuł nr	Zastosowanie	Gwint
90 25 01*	mocowanie poręczy	M 5 / M 6
90 25 04**	mocowanie poręczy	M 5 x 12
90 25 05**	mocowanie poręczy	M 6 x 10
90 25 02**	mocowanie prętów	M 6 x 25
90 25 03***	zaciski do szkła	M 8 x 20



Artykuł nr	Promień	Długość
	mm	mm
15 22 12	16,85	22,0
15 22 14	16,85	42,0
15 22 19	16,85	92,0
15 22 22	21,20	22,0
15 22 24	21,20	42,0
15 22 29	21,20	92,0



Artykuł nr	Gwint	Długość
		mm
90 25 06	M 8	19



Artykuł nr
90 01 20

## Akcesoria



Artykuł nr	Ø
90 20 05	10
90 20 06	12



Artykuł nr	Długość	Gwint
	mm	
90 20 08	50	drewno 6
90 20 09	80	drewno 8



Artykuł nr	Długość	Gwint
	mm	
90 21 01	100	M 10
90 21 02	120	M 12



Artykuł nr	Gwint
90 01 01	M 6
90 01 02	M 8



Artykuł nr
90 01 21



Artykuł nr
90 01 22



Artykuł nr
90 01 23



Artykuł nr	Ø	Dla rury
	mm	mm
90 01 12	22,0 x 5,0	42,4 x 2,0
90 01 13	22,0 x 4,5	42,4 x 2,6
90 01 10	29,0 x 5,0	33,7 x 2,0
90 01 11	29,0 x 4,5	33,7 x 2,6